









CONTENTS:

- ° recoil handle
- ° release pin
- ° 20' tether strap
- ° tether storage bag

Watch the video at TailTether.com
 Customer Service: sales@drakeinc.com

1. Secure the tail of the airplane to a stationary object by one of the methods below.
2. Insert the release pin and roll the airplane forward to take up any slack.
3. Reel out the line from the recoil handle, set the lock, and place the handle in the cockpit.
4. Set the engine controls and start the engine.
5. Once safely in the cockpit, unlock the recoil handle, pull the release pin and reel in the line.
6. If using the tether, coil it up and return it to the storage bag.



IMPORTANT: Hand-propping an aircraft is very dangerous and can result in serious injury or death. The TailTether is provided as is without any guarantees or warranty. The supplier makes no warranties of any kind, either express or implied, including but not limited to warranties of merchantability, fitness for a particular purpose, of title, or of noninfringement of third party rights. Use of the product by user is at the user's risk.